

DRFIBERGLASS.COM
"SERVING THE
TRI-STATE AREA"
Phone (973) 455-8804
Fax (732) 929-9260

These procedure sheets are Copyrighted by
DRFIBERGLASS.COM

Here is our procedure for fiberglassing decks:

- 1. We use 11/2 ounce fiberglass matt**
- 2. We start with putting resin on the wood**
- 3. Then we put down the first layer of fiberglass**
- 4. Then we wet it out with resin**
- 5. Then we roll out the fiberglass with a roller to get all the air out and make flat**
- 6. Final layer is a color coat**
- 7. The pan is approx. 1/4" thick when we are done**
- 8. Curing time take approx. 24-48 hours**

MAINTENANCE FREE
NON-SKID SURFACE

WATERPROOF COATING