

# DR FIBERGLASS

**OFFICE# 973-897-5816**

**FAX# 732-929-9260**

**DECK PREPARATION**  
**IF YOU ARE PREPARING THE DECK YOURSELF**  
**PLEASE FOLLOW THESE GUIDELINES.**

Remove 8" min. of existing siding and remove your door.

Dry, clean 3/4" T&G AC or BC plywood is best to use.

1/4" per 4' pitch on 16" on center joists.

1x2 Azek edges installed after plywood is best to use.

Keep plywood clean and dry and install the same morning

we are scheduled to fiberglass.

Do not nail to close to plywood seams as this may cause

"rosebuds" or the wood to splinter creating bumps and

air pockets.

Keep holes, spaces and unevenness to a minimum.

(Remember, our work will only look as good as your work.)

**DR FIBERGLASS**  
**FIBERGLASS DECKS, SHOWERPANS AND ROOFS**  
Office (973) 897-5816 Fax (732) 929-9260  
Drfiberglassinc@gmail.com  
Find us on the web @ Drfiberglass.com